

SPARE PARTS CATALOGUE

LAWN MOWERS: CONSUMER WALK-BEHINDS: HUSQVARNA LC 140P


Spare Parts List

SPARE PARTS LIST

LAWN MOWERS: CONSUMER WALK-
BEHINDS

HUSQVARNA LC 140P


A LC 140P CHASSIS



LAWN MOWERS: CONSUMER WALK-BEHINDS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599349369	BASTIDOR	CHASSIS	1
2	599349371	CONJUNTO DE TAPA	FRONT COVER	1
3	599349373	ALERÓN	REAR DOOR	1
4	599349422	RUEDA	REAR WHEEL	2
5	599349385	EJE	WHEEL AXLE	1
6	599349417	MANGUITO	REAR AXLE SLEEVE	1
7	599349387	EJE	WHEEL AXLE	1
8	599349382	EJE	FRONT AXLE FIXING	1
9	599349367	RUEDA	FRONT WHEEL	2
10	599349398	CONJUNTO MANILLAR	HEIGHT ADJUSTMENT HANDLE	1
11	599349363	PLATE KIT	HEIGHT ADJUSTMENT PLATE	1
12	599349364	BARRA	HEIGHT ADJUSTMENT ROD	1
13	599349366	MUELLE	HEIGHT ADJUSTMENT SPRING	1








D LC 140P
GRASS HANDLING



LAWN MOWERS: CONSUMER WALK-BEHINDS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599349378	CONJUNTO BOLSA PARA HIERBA	GRASS BAG KIT	1


LC 140P
ENGINE



LAWN MOWERS: CONSUMER WALK-BEHINDS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	529347201	MOTOR	HS 123A	1
2	599349407	INSTALLATION KIT	BOLTS AND NUTS	1
3	599349376	CUBIERTA	BELT COVER	1
4	529737101	SOPORTE DE CUCHILLA	BLADE ADAPTER	1
5	599349374	CUCHILLA		1
6	537546001	ADHESIVO		1

B LC 140P
HANDLE



LAWN MOWERS: CONSUMER WALK-BEHINDS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599349362	CONJUNTO BRAZO DE FARDO	BAIL ARM	1
2	599349402	CONJUNTO MANILLAR	HANDLE AND SHEATH	1
3	599349397	EMPUNADURA	LOWER HANDLE	1
4	599349361	CONJUNTO BRAZO DE FARDO	BAIL ARM	1
5	529853401	CONJUNTO MANILLAR	HANDLE	1
6	599349360	KNOB ASSY	KNOB	1
7	599349391	CABLE	FLAMEOUT CABLE	1
8	599349379	MORDAZA	CABLE CLIP	1
9	529596001	KNOB ASSY	KNOB	2
10	599349380	SUPPORT KIT	HANDLE BRACKET	1
11	599349418	MANGUITO	ANTI FRICTION SLEEVE	1