

SPARE PARTS CATALOGUE


**LAWN MOWERS: CONSUMER WALK-BEHINDS: HUSQVARNA LC
141I SIN BATERÍA NI CARGADOR**

Spare Parts List

SPARE PARTS LIST


LAWN MOWERS: CONSUMER WALK-
BEHINDS

HUSQVARNA LC 141I SIN BATERÍA NI
CARGADOR




LAWN MOWERS: CONSUMER WALK-BEHINDS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	587586301	GRASSBAG		1
2	587911801	SOPORTE		1
3	587586001	CUBIERTA		1
4	587912301	TORNILLO		1
5	587586101	EMPUNADURA		1
6	579686701	TORNILLO		2




LAWN MOWERS: CONSUMER WALK-BEHINDS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	589969301	CONJUNTO MANILLAR		1
2	579686701	TORNILLO		1
3	579687501	TORNILLO		2
4	579688701	ARANDELA		2
5	579686501	ARANDELA		1
6	501490301	SOPORTE		1
7	579688801	MUELLE DE TORSIÓN		1
8	501490401	CUBIERTA		1
9	501491301	CUBIERTA		1
10	502429901	PERNO		2
11	587913301	TUERCA HEXAGONAL		4
12	587585801	BOTÓN		4
13	579688001	MANILLAR		1
14	501055601	PLACA		1
15	502259901	PERNO		2
16	502258701	ANILLO SEPARADOR		2
17	587913501	PERNO DE FIJACIÓN		2
18	501055501	PLACA		1
19	501055701	SOPORTE		3
20	501055401	CUBIERTA		2
21	502402101	PERNO		2



LAWN MOWERS: CONSUMER WALK-BEHINDS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	587585001	CUBIERTA DE RUEDA		2
2	501491501	CUBIERTA		2
3	587913501	PERNO DE FIJACIÓN		4
4	587912901	RODAMIENTO		8
5	501491601	RUEDA ENSAMBLADA		2
6	587914601	ARANDELA		4
7	579684601	PERNO		4
8	579684701	APOYO		1
9	579684801	EJE DELANTERO ENSAMBLADO		1
10	579684901	APOYO		1
11	587913101	TUERCA		8
12	587585101	CUBIERTA DE RUEDA		2
13	587585301	CUBIERTA DE RUEDA		2
14	587918001	RUEDA		2
15	587912701	ARANDELA		2
16	579685001	CONJUNTO EJE TRASERO		1
17	587585701	BOTÓN		1
18	502502701	EMPUÑADURA COMPLETA		1
19	587912601	TORNILLO		4
20	587913401	LOCK NUT		6
21	587910901	PLACA DE FIJACIÓN		2
22	587992401	PLACA DE FIJACIÓN		2
23	587917901	CUBIERTA		2
24	579685101	PERNO		2
25	587909901	SEGMENT		1
26	579685201	TUERCA		2
27	579685401	DECK		1
28	587915801	TUBING		2
29	587914901	MUELLE		1
30	579685301	BIELA		1
31	587913901	PERNO		4
32	579688101	SOPORTE		1
33	579687901	TUERCA		4
34	501054401	SOPORTE		1
35	502231001	BARRA		1
36	587915101	MUELLE		1
37	587915001	SOPORTE		1
38	501492001	CUBIERTA		1
39	579685501	TORNILLO		4
40	579685601	SOPORTE		1
41	579685701	PLACA		1
42	579689401	CONJUNTO DE PICADO		1
43	579857001	TAPÓN		1 42
44	579689301	BOTÓN		1 42
45	579689201	MUELLE		1 42
46	579689101	PLACA		1 42
47	579686701	TORNILLO		2 42
48	579856901	CUCHILLA		1 42
49	597681001	SUPPORT KIT		1



LAWN MOWERS: CONSUMER WALK-BEHINDS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	579684101	PERNO		1
2	579684201	ARANDELA ELÁSTICA		1
3	579684301	ARANDELA		1
4	501171601	MOWER BLADE		1
5	579684501	SOPORTE DE CUCHILLA		1
6	579685801	TUERCA		4
7	579685901	SOPORTE		1
8	579686001	ARANDELA		4
9	579686101	PERNO		4
10	598764301	MOTOR	600W, 36V. Local - 2050100162D.	1
10	598764302	MOTOR	Use in models after S/N 20191500001. Tyco - 2050100244A.	1
11	579686301	TORNILLO		4
12	598764501	MANDO	Local - 2108900031D	1
12	598764502	MANDO	Use in models after S/N 20191500001. Tyco - 2108900031E.	1
13	579686501	ARANDELA		3
14	579685501	TORNILLO		16
15	579686602	CABLE		1
16	579686801	PLACA		1
17	582029202	CABLE	Local - 2108900160A	1
17	582029203	CABLE	Use in models after S/N 20191500001. Tyco - 2108900027C.	1
18	579686901	LLAVE DE INTERRUPTOR		1
19	501489601	CAJA		1
20	579687001	MUELLE		2
21	501490201	SOMBRERETE		2
22	501490101	TECLA		1
23	501488501	CUBIERTA		1
24	501488701	CUBIERTA		1
25	501488401	CUBIERTA		1
26	579686701	TORNILLO		8
27	501488801	CUBIERTA		1
28	579687101	CABLE		1
29	501488301	CUBIERTA		1
30	579687501	TORNILLO		12
31	501489501	CUBIERTA		1
32	579843901	PESO		1
33	579687601	ARANDELA		4
34	501488901	CUBIERTA		1
35	501489101	ADHESIVO		1
36	579687701	MUELLE DE TORSIÓN		1
37	501489801	BISAGRA		2
38	579687801	MUELLE DE TORSIÓN		1